






INTELLIFILL LEVER NO-OP



Replace leverswitch, follow "Intellivalve Disassembly / Reassembly Instructions" to step 9 & review step 11 **Do not remove tubes.** Remove old switch and any excess adhesive, place new switch. Take care to dress all wires as they originally were.