

IntelliFill and Portion Control Supplemental Installation Instructions

Programmable IntelliFill Top-off Feature

To program a top-off, follow these steps:

1. Hold down the program (medium) button for 3 seconds until LED comes on solid.
2. Depress and hold the AutoFill lever, allowing drink to dispense (LED is solid) into a cup.
3. When contact is sensed, the drink dispense will halt and the LED will blink.
4. When the foam has gone down, press the program/medium button and the drink dispense will resume with the LED on solid.
5. When contact is sensed, the drink dispense will stop. This ends the sequence.
6. Remove the cup from the autofill lever.
7. Press and hold the program/medium button for 3 seconds to save/exit programming mode.
8. The LED will extinguish indicating the valve is in normal operating mode.



Hidden Top-Off
Programming Button

To clear top-off, repeat the above steps, except skip steps 4 and 5.

Programming Portion Control

The IntelliValve Portion Control model is different than predecessors. It programs and stores portion SIZE not dispense TIME values. Therefore it is normal for the dispense times to vary as needed to allow the valve to dispense the same quantity regardless of changes in system pressures during dispense.

The Portion Control model is pre-programmed at the factory with the following drink sizes:

Small Pushbutton	7 ounces / dispense
Medium Pushbutton	11 ounces / dispense
Large Pushbutton	16 ounces / dispense
X-Large Pushbutton	22 ounces / dispense



Hidden Programming Button

These are the default dispense volumes as shipped. There is no factory preset top-off volume for each size. The Portion Control model is initially set-up for manual top-off. Any of these drink sizes can be changed by reprogramming the membrane control switch (See IntelliValve Operator's Training & Service Manual).